



EHL-2

Operation Manual

Contents subject to change without notice

Version 1.0
11/2011

General Information

- Read and understand all operating instructions before using this product. Keep this manual for future reference.
- Exceeding the scale's capacity or dropping items on the scale can damage the weighing mechanism and/or affect the accuracy of the scale.
- Do not use or store the scale in high temperature, high humidity or high vibration conditions.
- Low battery voltage is indicated by **LLLLL**. Replace batteries before proceeding.
- Remove batteries from the scale when it will not be used for an extended period of time.
- Using a mild soap solution, dampen a cloth to clean the scale. Do not use any harsh chemical cleaners. Do not wash down or immerse the scale. Any liquid inside the scale can cause permanent damage.
- This scale does NOT come with an AC adaptor.

Specifications

Model	EHL-2-02	EHL-2-2K	EHL-2-5K
Max Capacity	7oz (200g)	4lb (2kg)	11lb (5kg)
Readability	0.01oz (0.1g)	0.1oz (1g)	0.1oz (1g)
Resolution	2000	2000	5000
Weighing Modes	Kg, g, lb/oz		
Display	5 digit LCD		
Operating Temp.	41° - 104° F (5° - 40° C)		
Power	Alkaline Batteries: 4 x "AA" size cells (included) AC Adapter: 6Vdc/500mA with central positive (not incl.)		
Pan Diameter	5.8" (148mm)		
Base Dimensions	9.5" x 6.7" x 1.5" (L x W x H) 242 x 170 x 39mm (L x W x H)		

Operation

1. Place batteries (included) in the battery compartment on the bottom of the scale ensuring proper polarity, or plug in a suitable AC adaptor (not included).
2. Place the scale on a flat, stable surface.
3. Press the **TARE/ON** key to power on. When **0** appears the scale is ready for weighing.
4. Press the **UNITS** key to change the unit of measure from **g** to **kg** to **lb/oz**.
5. Set tare if desired.
6. Begin weighing.
7. Turn the scale off by pressing the **OFF** key. To save battery power, the scale will automatically turn off after 90 seconds with no key activity or weight change.

Setting the Tare Weight

1. Place an empty container on the platform and press the **TARE/ON** key. The display will return to zero, eliminating the weight of the container.
2. Put the material or object to be weighed in the container. The net weight will be displayed.
3. To exit tare mode, remove all weight from the scale. The display will show a negative weight. Press the **TARE/ON** key to return the display to zero, eliminating the weight of the container.

One Year Limited Warranty

MeasureTek products covered in this manual are guaranteed to be free from defects in material and workmanship for a period of one year after date of purchase. Misuse, accidental damage, overload, alteration, and improper installation are expressly excluded. Any product which is determined to be defective in material or workmanship within this time period may, as the exclusive remedy, be returned to an authorized MeasureTek distributor or service center, freight prepaid with prior return authorization, to be repaired or replaced at the manufacturer's option. MeasureTek's liability under this warranty is limited to the repair or replacement of the defective product and in no event shall MeasureTek be liable for consequential or indirect damages.